



# CUKW Series

ø10, ø16, ø20, ø25, ø32



## Construction

With auto switch

ø10



ø16 to ø32



\* The numbers correspond with those in the "Construction" of the CUKW series in the **Web Catalog**.

### Seal Kit List

No.	Description	Material	Note
20	Piston seal	NBR	
21	Rod seal		
22	Gasket		

### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
10	CUW10D-PS	Set of nos. 20, 21, 22
16	CUW16D-PS	
20	CUW20D-PS	
25	CUW25D-PS	
32	CUW32D-PS	

\* ø6 cannot be repaired.

\* The seal kit includes 20, 21, 22. Order the seal kit based on each bore size.

\* The seal kit includes a grease pack (10 g).

Order with the following part number when only the grease pack is required.

**Grease pack part no.: GR-S-010 (10 g)**